

BIG HORN

SRFP22304

Corten Steel Fire Bowl & Removable Stainless-Steel Plancha Grill



Installation, Operation, Safety & Maintenance Manual

Technical Specifications

Brand	BIG HORN
Model	SRFP22304
Country of Manufacture	Germany
Fuel Type	Wood & Coal
Fire Bowl Material	Corten Steel
Cooking Plate Material	Stainless Steel
Cooking Plate Thickness	8 mm
Cooktop	Removable
Width	31.5 in
Depth	31.5 in
Height	23.62 in
Weight	68 lb

Package Contents

Fire bowl, removable 8 mm stainless-steel cooking plate, assembly hardware, and instruction manual.

Assembly Instructions

Place the unit on a level, non-combustible surface. Assemble supplied hardware. Install the cooking plate and ensure it sits evenly and securely before use.

Safe Installation Location

Maintain at least 2 m (6.5 ft) clearance from combustible materials, structures, furniture, and vegetation. Outdoor use only.

First Firing Procedure

Light a small fire and gradually heat the cooking plate for 30–45 minutes. This conditions the cooking surface and removes any manufacturing residues.

Fuel Requirements

Use only dry seasoned hardwood, charcoal, or coal. Do not use gasoline, alcohol, lighter fluid, treated timber, painted wood, or household waste.

Cooking Guidance

The cooking plate develops natural heat zones. The area closest to the center opening is hottest; the outer edge is cooler and suitable for warming food.

Safety Warnings

Surfaces become extremely hot during operation. Keep children and pets away. Never leave the fire unattended. Do not move the unit while hot.

Removable Cooking Plate

Allow the unit to cool completely before removing the plate. Use heat-resistant gloves. Clean and dry the plate thoroughly before storage.

Corten Steel Care

Corten steel naturally develops a protective rust-colored patina. Color variation and weathering are normal and not considered defects.

Cleaning & Maintenance

Remove ash after each use. Because the bowl has no drainage holes, remove standing water promptly and keep the unit covered when not in use.

Storage

Store under a weatherproof cover. Ensure all components are dry before long-term storage.

Warranty

Normal discoloration, patina development, and wear from regular use are excluded from warranty coverage.